

ELECTRONIC

# Enchanted Palace™

## Assembly Instructions


**CONTENTS:** Plastic wand, 3-D palace gameboard with 4 plastic turrets, entranceway and 5 plastic pawns, electronic base unit, 4 plastic glitter girl figures with matching bows and crowns, 5 plastic pawn stands, cardboard parts sheet, 2 label sheets, rubber bands.

### ✿ Wand ✿

**Parts needed:** plastic wand with battery door and screw, label sheet


Insert 2 "AAA" size alkaline batteries into compartment as shown in Figure 1. Be sure to match the "+" and "-" symbols according to the diagram inside. Using a Phillips head screwdriver, screw on door.

**Figure 1.**  
Insert batteries.




Carefully apply 3 labels to wand as shown in Figure 1A.

**Figure 1A.**  
Apply wand labels.



**Test Batteries:** Hold the wand and gently press its light tip against a hard surface. The wand's light should glow brightly. See Figure 1B. If it does not, your batteries may be weak or improperly installed.



**Figure 1B.**  
Press down on wand's tip and see it glow!


**Caution:** Batteries may leak if improperly installed. Remove batteries when game will not be used for an extended period of time. Never mix battery types. NOTE: Be sure to store your wand so it does not light up in the box between games.

### Base Unit ✿

**Parts needed:** base unit, label sheet


Carefully apply screen label over the clear plastic window on the top of the base unit. See Figure 2.

**Figure 2.**



Turn the base unit upside down. Use a Phillips head screwdriver to remove the screw from the battery compartment door. Insert 4 "AA" size alkaline batteries into the battery compartment as shown in Figure 2A. Be sure to match the "+" and "-" symbols according to the diagram inside. Then replace the door and the screw.

**Figure 2A.**  
Insert batteries.



**Test Batteries:** Turn the base unit right-side up. Press the ON button. You should hear the Good Queen ask, "Who will help me?" If you do not hear this, your batteries may be weak or improperly installed. (See Caution notice at left.) NOTE: The unit will continue to talk and beep, but will shut off automatically after 1 minute.



# ✿ 10-Step Palace Assembly ✿

Figure 3 shows an assembled game. Refer to it as you put the palace together in 10 easy steps.

**Parts needed:** cardboard platform, electronic base unit, 7 cardboard palace walls, 4 plastic turrets, 1 plastic entranceway, 5-piece plastic tower plus 2 rubber bands, and cardboard Good Queen.

Before you begin, carefully punch out all 7 palace walls and the Good Queen from the parts sheet. Punch out all slots. Carefully remove the 4 plastic turrets, entranceway, and 5 tower pieces from the plastic runner. Discard plastic waste.


Figure 3. 10-Step Assembly



## Step 1. Platform

The platform is packed upside-down. Turn it over and punch out all slots and holes. Discard waste. Then place the platform into the box bottom to form the gameboard. See Figure 4. NOTE: Area under gameboard must remain empty.


Figure 4.



## Steps 2 & 3. Base Unit & Throne Wall

Insert the electronic base unit into the gameboard's numbered slots (1, 2, 3) so it rests flat on the gameboard. Then slide the Throne Wall (A, B) into its matching lettered gameboard slots. (Wall will hook onto the back of the base unit.) See Figure 5.


Figure 5.



## Step 4. Queen's Tower Wall

Fold the Queen's Tower Wall (C, D, E) as shown in Figure 6 and insert it into its matching lettered gameboard slots.

Figure 6.




## Step 5. The Queen's Tower

Parts needed: 5 plastic tower pieces (Front, Back, Platform, and 2 Doors), the cardboard Good Queen and 2 rubber bands.


♥ First, fit the cardboard Good Queen inside the plastic Tower Back as shown in Figure 7.

Figure 7.




- ♥ Then snap-fit the 2 Doors onto the Tower Front. (Make sure the words "INSIDE OF DOOR" are not showing faceup as you snap a door into place. Snap door's top hinge in place before bottom hinge.) See Figure 7A.

Figure 7A.



- ♥ Press-fit the Tower Front onto the Tower Back. See Figure 7B.

Figure 7B.



- ♥ Open doors and slide the assembled door unit into the Tower Platform until it snaps in place. See Figures 7C and 7D.

Figure 7C.

Keep the doors wide open!






Figure 7D.



- ♥ With doors open, attach rubber bands underneath the Platform as shown in Figure 7E.


Figure 7E. Underside of Platform

**CORRECT ASSEMBLY**




Be sure the rubber band hooks around the pin (see above) and does not slip across as shown below.

**INCORRECT ASSEMBLY**




- ♥ Close doors and test them as shown in Figure 7F. (If a door doesn't open, check the rubber bands.)

Figure 7F.




- ♥ With the doors closed, place the assembled Queen's Tower on top of the Queen's Tower Wall as shown in Figure 7G. Be sure the Queen's Tower also clips onto the Throne Wall as shown in Figure 8B.

Figure 7G.




## Steps 6 & 7. Rear Turrets


Gently bend Wall (F, G, H, I) along its scored lines. Attach a turret. Insert Wall's lettered tabs into the matching lettered gameboard slots. Do the same for other Wall (J, K, L, M). See Figures 8, 8A and 8B.



**Figure 8A.**  
Leave a slight gap on the side that attaches to the Throne Wall.




**Figure 8B.**  
Be sure that the front of the turrets also clip onto the Throne Wall.





## Step 8. Entrance

Attach the plastic entranceway to the Entrance Wall (N, O). Then insert the assembled Entrance Wall (N, O) into its matching lettered gameboard slots. See Figure 9.



## Steps 9 & 10. Front Turrets

Gently bend Wall (P, Q, R, S) along its scored lines. Attach a turret, leaving a gap on the side that attaches to the Entrance Wall like in Figure 8A. Insert Wall's lettered tabs into the matching lettered gameboard slots. Do the same for other Wall (T, U, V, W). See Figures 10 and 10A.




## Girls, Pawns & Tokens

**Parts needed:** 4 plastic 2-piece girls with matching bows and crowns, 4 frog pawns, 4 plastic stands, 13 tokens (4 key tokens, 4 lantern tokens, 4 mirror tokens, 1 magic dust token), Evil Witch pawn.


Carefully remove the 2-piece girls and their matching crowns and bows from the plastic runner. Press-fit each girl together to make 4 color girls. See Figure 11.

Figure 11.  
Press-fit girl together.



Place a matching color bow on the head of each girl. See Figure 11A. Set the crowns aside.

Figure 11A.



Carefully punch out the 4 frog pawns, 4 key tokens, 4 lantern tokens, 4 mirror tokens, 1 magic dust token and the Evil Witch pawn from the cardboard parts sheet. Discard waste. Insert each frog pawn and the Evil Witch into a pawn stand.

See separate instruction booklet  
for complete gameplay rules.



© 1994 Milton Bradley Company. All Rights Reserved. 4500-X  
Milton Bradley Company, P. O. Box 1247, East Longmeadow, MA 01028